


Shift the mattress so you can work around the side rail of the bed



Fit the clamp over the side rail of the bed



Fit the washer with the large holes over the clamp



Align slot in the leg lifter with the holes in the clamp and fit the washer with the small holes over the clamp



Screw in the two bolts



Position the leg lifter where you want it on the bedside. Ensure it is also the correct height.



Tighten the bolts



Check that the leg lifter works freely